

GKB Infiller



Are you looking for a way to evenly distribute infill over your field? The GKB Infiller is the perfect machine for this. The Infiller can apply infill in 2 directions and is therefore suitable for several types of infill, such as sand, SBR rubber and cork. Depending on the chosen infill, side walls can be used to increase the content of the bunker to 4 m³. The Infiller is powered by a Kubota diesel engine, so it does not need a towing vehicle. The combination of a GKB machine and a Kubota engine make the Infiller the perfect machine for the job.



To regulate the amount of litter, the metering valve can be opened up to 100mm. Stirrers are present in the bunker to keep the material moving and to guarantee a smooth outflow. For safety, a collapsible grid is mounted on the Infiller. In addition, the Infiller is equipped with a travel lock, so that the machine cannot drive away unintentionally during adjustment. This way you can spread your field safely and efficiently.

The most unique aspect of the Infiller is the rotating cab. In this way, spreading can take place in front of the machine, so that the infill is in the field before it is driven over. It is possible to partially tip the bunker while driving. This makes it possible to oversee the spreading quantity at the front of the machine. Everything to make your work as easy as possible!

THE WORKER IS KING



Infiller

Specifications:

Type	IF150
Working width	160 cm / 63"
Dimensions (L x W x H)	250 x 175 x 230 cm / 99 x 69 x 91"
Dimensions during transport (L x W x H)	250 x 175 x 180 cm / 99 x 69 x 71"
Wheelbase	150 cm / 59"
Capacity bunker (sand)	1,5 m ³ / 53 ft ³
Capacity bunker (rubber)	3 m ³ / 106 ft ³
Capacity bunker (cork)	4 m ³ / 142 ft ³
Weight	1350 kg / 2975 lbs
Tires	Ø50 cm / Ø70 cm / Ø20" / Ø28"
Engine	
Power	25 hp
Fuel	Diesel
Cylinders	4
Engine displacement	1500 cc
Max. rpm	2300 rpm
Fueltank capacity	30 l
Max. noise	80 dB
Driving speed	0 - 15 km/h / 0 - 9 mph*
	The working speed depends on the desired thickness of the infill. With a view to safety, you must estimate yourself what a suitable speed is.
Functions	
Side walls	Depending on the infill material: Sand: no side walls Rubber: side walls of 60 cm Cork: Side walls of 60 + 40 cm
Stirrers	5 stirrers, optionally 2 stirrers can be switched off.
Comments	
*	The working speed depends on the desired thickness of the infill. With a view to safety, you must estimate yourself what a suitable speed is.

THE WORKER IS KING